Quick Shot

USER'S GUIDE

for Wii™

dreamGEAR®

www.dreamgear.net

User's Guide

- 1 Quick Shot
- User's Guide/Warranty Card
- Registration Card

The Quick Shot is designed for use with the Wii Remote, and features a cable pass through area for games requiring both the Wii Remote and Nunchuck.

INSTRUCTIONS:

Note: The Quick Shot is not compatible with any sleeves or jackets that go over the Wii Remote

1. To insert the Wii Remote into the Quick Shot, first open the cable pass-through area by squeezing the hammer lock on the back of the gun. Pull the cable pass-through cover back, allowing it to hang freely from its hinge.

2. Lift the blue A button actuator and insert the Wii Remote into the Quick Shot with the buttons facing upward and the directional pad directly behind the front sight. Slide the Wii Remote forward until it locks into place, and return the A button actuator to its original position. The A button actuator will click when it is locked into place.

If using the Wii Remote only, continue to step 4.

3. To attach the Wii Nunchuck with the Wii Remote, first insert the Nunchuck plug into the Quick Shot's handle by passing it through the gap in the bottom of the handle. Pull the cord through the pass-through area and plug it into the Wii Remote.

4. Complete the set-up of your Quick Shot by squeezing the hammer lock and replacing the cable pass-through cover to its original position. If attached, ensure that the Nunchuck's cable is aligned with the cable hole in the bottom of the handle.

5. Your Quick Shot is now ready to use. The primary trigger activates the B button on the Wii Remote and the secondary trigger activates the A button.

FOR TECHNICAL SUPPORT PLEASE CONTACT:
1-877-999-DREAM or support@dreamgear.net